

Inteset INT-422-3 Key Map



Location	Inteset Remote Button Label	02615 Apple TV Preprogrammed "A" Device	04000 Xbox One Preprogrammed "B"	01272 MCE Preprogrammed "C" Device	03061 Roku Preprogrammed "D" Device	04918 Nvidia Shield 1st Gen & Pro Model
1	SET	Set	Set	Set	Set	Set
2	A	Pre-programmed	----	----	----	----
3	B	----	Pre-programmed	----	----	----
4	C	----	----	Pre-programmed	----	----
5	D	----	----	----	Pre-programmed	----
6	Power (toggle)	Standby-Pause\Play-Select	Power On\Off	Power	----	Power
7	Menu	Menu-Back	Menu	Green Button-Go To MCE Menu	Home-Menu	Home-Menu
8	Info	----	View	Details-More Info-Refresh	Info-Options	----
9	Guide	----	OneGuide	Guide	Movie Store-Fandango	Shield Hub
10	Exit	Menu-Back	Back	Back	Back	Return
11	Up	Up-Volume Up	Menu Up	Menu Up	Menu Up	Menu Up
12	Down	Down-Volume Down	Menu Down	Menu Down	Menu Down	Menu Down
13	Left	Left-Search\Skip Reverse	Menu Left	Menu Left	Menu Left	Menu Left
14	Right	Right-Search\Skip Forward	Menu Right	Menu Right	Menu Right	Menu Right
15	OK	Standby-Pause\Play-Select	OK-Select	OK	OK	OK
16	Red	----	B-Red	Recorded TV	Netflix	A
17	Green	----	A-Green	My Music	YouTube	B
18	Yellow	----	Y-Yellow	My Pictures	Amazon	X
19	Blue	----	X-Blue	My Movies\Videos	Pandora	Y
20	Stop	----	Stop	Stop	----	Stop
21	Display	----	Display-Home	Display-DVD Menu	----	----
22	Record	----	----	Record	----	----
23	Rewind	Left-Search\Skip Reverse	Search Reverse	Rewind	Search Reverse-Page Back	Search Reverse
24	Play	Standby-Pause\Play-Select	Play	Play	Play-Pause	Play
25	Fast Forward	Right-Search\Skip Forward	Search Forward	Fast Forward	Search\Page Forward	Search Forward
26	Skip Reverse	Left-Search\Skip Reverse	Skip Reverse	Replay-Skip Reverse	----	Left Trigger
27	Pause	Standby-Pause\Play-Select	Pause	Pause	Play-Pause	Pause
28	Skip Forward	Right-Search\Skip Forward	Skip Forward	Skip Forward	----	Right Trigger
29	Volume Up	Up-Volume Up	Volume Up	Volume Up	----	Volume Up
30	Volume Dn	Down-Volume Down	Volume Down	Volume Down	----	Volume Down
31	Mute	Down-Volume Down	Mute	Mute	----	Mute
32	Last	----	----	----	Instant Replay	----
33	Channel Up	----	Channel Up	Channel\Page Up	----	Gas-Right Bumper
34	Channel Dn	----	Channel Down	Channel\Page Down	----	Brake-Left Bumper
35	1	----	1	1	----	1
36	2	----	2	2	----	2
37	3	----	3	3	----	3
38	4	----	4	4	----	4
39	5	----	5	5	----	5
40	6	----	6	6	----	6
41	7	----	7	7	----	7
42	8	----	8	8	----	8
43	9	----	9	9	----	9
44	0	----	0	0	----	0
45	Input	----	----	Network Selection	----	----
46	Enter	----	Enter	Digit Enter	OK	----
47	Star	----	----	----	Rdio	----
48	Circle	----	----	----	Vudu	----
49	Triangle	----	----	----	Crackle	----
50	Live	----	----	Live TV-Jump	SlingTV	Language
51	Eject	----	Eject	----	----	----
52	Diamond	----	----	----	CinemaNow	----
53	Square	----	----	----	Google Play	----
54	Zoom	----	----	Zoom	----	----